

## Collecting Hexavalent Chromium EPA 218.7

### Bottle Requirements

125ml HDPE plastic WM, pH>8 w/  
buffer

### Sampling Instructions

1. Label the sample bottles and fill out the COC.
2. If sampling from tap flush through the sampling point until main distribution water is coming through the sampling point (2-3 minutes).
3. Fill the bottles for the analysis to their shoulder. Cap and mix the samples.
4. All samples must be placed on ice. If received next day the samples must be less than 6°C. If possible, deliver to the lab the same day that they are taken.

*Note: Holding time is 5 days unless frozen.*



### 3 Locations in Oklahoma

#### **Accurate – Stillwater**

505 South Lowry Street Stillwater, OK 74074  
Fax (405) 372-5396

#### **Accurate – Tulsa**

6558 East 40<sup>th</sup> Street Tulsa, OK 74145  
Fax (918) 663-6300

#### **Accurate – OKC**

12036 North Penn Ave. Okla. City, OK 73120  
Fax (405) 751-3108

*Need a quote or have questions?*

*Call our toll free number (800) 516-LABS  
or visit [www.accuratelabs.com](http://www.accuratelabs.com)*